



Directions for use with NET LED Slimline Flood Light

1. A plastic dust cap for PIR/Photocell mounting can be found on the bottom of all compatible LED Slimline Flood Lights.
2. Unscrew the plastic dust cap and remove.
3. Remove the Shorting Plug from the base of the Flood Light unit. DO NOT throw these away as they will be required should you choose to remove the PIR/ Photocell sensor from the unit.
4. Insert the PIR/Photocell sensor into the connection port. Ensure twist-lock connector is engaged to hold the PIR/Photocell securely in place and form a water-proof seal.