







GIRDER SHELF
FURNITURE
INSTALLATION MANUAL





CONTENTS





- 1** LOCATE THE GUARD RAIL IN THE POSITION THAT IS DESIRED, AND USE TWO COIN SCREWS TO FIX IT IN PLACE. ENSURE THE SCREWS ARE NOT CROSS-THREADED. USE FINGERS ONLY, NO SCREW DRIVERS








OR




- 2** CERTAIN ITEMS IN THE RANGE WILL NOT FIT INTO A 4 LUG BOX. IF SUCH A BOX HAS BEEN PREVIOUSLY INSTALLED THE TOP AND BOTTOM LUGS SHOULD BE REMOVED OR BENT BACK TO AVOID CONTACT WITH THE INTERIOR.






3 CERTAIN ITEMS IN THE RANGE WILL NOT FIT INTO A 4 LUG BOX. IF SUCH A BOX HAS BEEN PREVIOUSLY INSTALLED THE TOP AND BOTTOM LUGS SHOULD BE REMOVED OR BENT BACK TO AVOID CONTACT WITH THE INTERIOR.





4




SCREW TOGETHER A COIN CAP AND A COIN SCREW MOUNTING COMPONENT TOGETHER, THROUGH THE TOP HOLES (ONE EACH SIDE) IN THE HANGER SHELF BODY.





5 CERTAIN ITEMS IN THE RANGE WILL NOT FIT INTO A 4 LUG BOX. IF SUCH A BOX HAS BEEN PREVIOUSLY INSTALLED THE TOP AND BOTTOM LUGS SHOULD BE REMOVED OR BENT BACK TO AVOID CONTACT WITH THE INTERIOR.




6



TIGHTEN THE BOTTOM COIN SCREWS ON BOTH SIDES.



7



[end. **ORDINARY**]

