

DRV3001050

Installation instructions | Consignes d'installation



collingwood

DRV3001050/
FLS-42-1050 LD AV

LED+
LED-

AC-N
AC-L

L 220-240V AC
N - 50/60 Hz

DIP switch settings/ Paramètres des commutateurs DIP

Iout DC	1	2	3	4
300mA	-	-	-	-
350mA	ON/Sur	-	-	-
400mA	-	ON/Sur	-	-
450mA	ON/Sur	ON/Sur	-	-
500mA	-	-	ON/Sur	-
550mA	ON/Sur	-	ON/Sur	-
600mA	-	ON/Sur	ON/Sur	-
650mA	ON/Sur	ON/Sur	ON/Sur	-
700mA	-	-	-	ON/Sur
750mA	ON/Sur	-	-	ON/Sur
800mA	-	ON/Sur	-	ON/Sur
850mA	ON/Sur	ON/Sur	-	ON/Sur
900mA	-	-	ON/Sur	ON/Sur
950mA	ON/Sur	-	ON/Sur	ON/Sur
1000mA	-	ON/Sur	ON/Sur	ON/Sur
1050mA	ON/Sur	ON/Sur	ON/Sur	ON/Sur

en

Installation

- Set the dipswitches to the correct output current (30W panel = 750mA, 40W panel = 1000mA).
- Connect the output of the driver (plug and play connector) to the panel.
- Connect driver to the mains supply.

Installation data

- Isolate the mains supply, prior to wiring.
- This unit must be wired by a qualified electrician or suitable competent person.
- For use with 30W (750mA) and 40W (1000mA) LED panels.
- Do not exceed maximum rated output power of the driver.

fr

Installation

- Réglez les commutateurs DIP sur le courant de sortie correct (panneau 30W = 750 mA, 40W panneau = 1000mA).
- Connectez la sortie du driver (connecteur plug and play) au panneau.
- Connectez le driver à l'alimentation secteur.

Données d'installation

- Isolez l'alimentation secteur avant le câblage.
- Cet élément doit être câblé par un électricien qualifié ou une personne compétente.
- À utiliser avec les panneaux LED 30W (750mA) et 40W (1000mA).
- Ne dépassez pas la puissance de sortie nominale maximale du driver.

Rated voltage / Tension nominale	220 - 240V AC 50/60Hz
Input current / Courant d'entrée	0,3A max / 0,3A max
Power / Puissance	42W max
Power factor / Facteur de puissance	>0.9 / >0,9
Inrush current / Courant d'appel	9A 0.048ms



Disposal of this product should be separate from household waste. Please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resource. Household users should contact their local government office for details of where and how they can take these items for environmentally safe recycling.



Ce produit ne doit pas être éliminé avec les ordures ménagères. Merci de le séparer des autres déchets et de le recycler de manière responsable afin de promouvoir la réutilisation des ressources matérielles. Les consommateurs doivent contacter leurs autorités locales pour plus d'information quant aux lieux et méthodes de recyclage en accord avec la protection de l'environnement.



5 year warranty
5 ans de garantie