

Installation Instructions






Instrucciones de instalación, Instructions d'installation, Installationsanleitung, إرشادات التركيب,
Installatie-instructies, Instruções de instalação, Installatie-instructies,
設置手順説明, Οδηγίες εγκατάστασης



Product Code:(AHUEMKIT/LI)



Master
Translations
QR Link



LED Indication		Description	Status	Manual Mode	Self-Test Mode
		Green Permanently On	System Healthy	✓	✓
		Green Permanently Off	Emergency Mode:Mains failure or mains disconnected	✓	✓
		Emergency Light Fault		✓	N/A
		Functional Test Running		N/A	✓
		Red Fast Flash (0.1s on - 0.1s off)	Duration Test Running	N/A	✓
		Red Permanently On	Battery Fault	✓	✓
		Red Slow Flash (Flashes once every 3s)	Duration Fault	N/A	✓
		Red Slow Flash (Flashes twice every 3s)	Load Fault	N/A	✓


Ansell Electrical Products
Unit 6B, Stonecross Industrial
Park,
Yew Tree Way,
Warrington,
WA3 3JD

Ansell (Sales & Distribution)
Unit 2, M2 Business Park,
Duncrue Street,
Belfast,
BT3 9AQ

Ansell (Sales & Distribution) Republic of Ireland Limited
Unit G1, Block G,
Calmount Park, Calmount Avenue
Dublin 12,
D12 TH56

www.ansell-lighting.com

Hawk Wiring Diagram with Plugs



Hawk Wiring Diagram without Plugs

