

LAMP SPECIFICATIONS:	
Voltage	220-240V
Frequency	50Hz
Nominal lumens	1371 lm
Wattage	23W
Nominal life time of the lamp	10,000 hrs
Number of switching cycles before premature lamp failure	30,000
Colour temperature	6400K
Warm-up time up to 60 % of the full light output	40s
Dimmable	No
Lamp dimensions (mm)	140 x 59
Lamp mercury content to an accuracy of 0.1mg	2.5
Cap type	ES (E27)
Rated Wattage	22.5W
Rated luminous flux	1371 lm
Rated lamp lifetime	10,000
Colour rendering index Ra	80%
Lamp power factor	0.55
Lumen maintenance factor at end of nominal life	50%
Starting time	0.9s

Eterna

FL124B



This luminaire is compatible with bulbs of the energy classes:



This luminaire is sold with a bulb of the energy class: **A**

874/2012



Eterna

CFL23W



A

22.50 kWh/1000h

EVENTUALLY, YOU MAY WANT TO REPLACE THIS PRODUCT:

Regulations require the recycling of Waste from Electrical and Electronic Equipment (European "WEEE Directive" effective August 2005—UK WEEE Regulations effective 2nd January 2007). Environment Agency Registered Producer: WEE/ GA0248QZ.

WHEN YOUR PRODUCT COMES TO THE END OF ITS LIFE OR YOU CHOOSE TO REPLACE IT, PLEASE RECYCLE IT WHERE FACILITIES EXIST - DO NOT DISPOSE WITH HOUSEHOLD WASTE.

CLEANING:

Disconnect the power and clean the exterior only of this fitting with a moist (not wet) cloth.

Do not use any chemical or abrasive cleaners.

IF YOU EXPERIENCE PROBLEMS:

If you believe your product is defective, please return it to the place where you bought it. Our Technical Team will gladly advise on any Eterna Lighting product, but may not be able to give specific instructions regarding individual installations.

For breakage information visit:
www.etera-lighting.co.uk



Issue 2013



FOR PRODUCT ADVICE:

• T: 01933 673 144
• F: 01933 678 083
• E: sales@etera-lighting.co.uk

Visit our website:

www.etera-lighting.co.uk



INSTALLATION INSTRUCTIONS

A guide for qualified electricians



Pack contents:

1 x Fitting
1 x 23W ES CFL lamp

Model:
FL124B

23W Low Energy Floodlight

These instructions are provided as a guideline to assist you.

**PLEASE READ THESE INSTRUCTIONS BEFORE INSTALLATION
AND RETAIN FOR FUTURE REFERENCE**

READ THIS FIRST:

Check the pack and make sure you have all of the parts listed on the front of this booklet. If not, contact the outlet where you bought this product.

This product contains glass, care must be taken when assembling, fitting or handling to prevent personal injury or damage to the product.

This light fitting must be installed by a competent person in accordance with the Building Regulations making reference to the current edition of the IEE Wiring Regulations (BS7671). The Building Regulations may be obtained from HMSO or viewed and downloaded from www.communities.gov.uk following the link for Building Regulations.

As the buyer, installer and/or user of this product it is your own responsibility to ensure that this fitting is fit for the purpose for which you have intended it. Eterna Lighting cannot accept any liability for loss, damage or premature failure resulting from inappropriate use.

The lamps (bulbs/tubes) supplied with this fitting are consumable parts and therefore may be outside of any warranty offered.

Switch off the mains before commencing installation and remove the appropriate circuit fuse.

When working at heights, please use a suitable platform.

Disconnect the fitting from the electrical supply before flash or high voltage testing.

Suitable for indoor and outdoor use.

This product is suitable for installation on surfaces with normal flammability e.g. wood, plasterboard, and masonry. It is not suitable for use on highly flammable surfaces (e.g. polystyrene, textiles).

Before making fixing hole(s), check that there are no obstructions hidden beneath the mounting surface such as pipes or cables.

The chosen location of your new fitting should allow for the product to be securely mounted and safely connected to the mains supply (lighting circuit).

When choosing the location for your new fitting, ensure that the fixings will be anchored in a solid surface e.g. concrete, brick or a joist—do not fix directly onto panelling, cladding, plasterboard etc.

If the location of your new fitting requires the provision of a new electrical supply, the supply must conform with the requirements of the Building Regulations making reference to the current edition of the IEE Wiring Regulations (BS7671).

This product is designed for permanent connection to fixed wiring: this should be either a suitable lighting circuit (protected with a 5 or 6 Amp MCB or fuse) or a fused spur (with a 3 Amp fuse) via a fused connection unit.

We recommend that the supply incorporates a switch for ease of operation.

Make connections to the electrical supply in accordance with the following code:

Live - Brown or Red
Neutral - Blue or Black
Earth - Green and Yellow

When making connections, ensure that the terminals are tightened securely and that no strands of wire protrude. Check that the terminals are tightened onto the bared conductors and not onto any insulation.

This product must be connected to Earth.

IMPORTANT: Always switch off at the mains before changing the lamp.

You are advised at every stage of your installation to double-check any electrical connections you have made. After you have completed your installation there are electrical tests that should be carried out: these tests are specified in the Wiring Regulations (BS7671) referred to in the Building Regulations.

INSTALLATION:

01. Choose the location for your new floodlight giving consideration to all of the conditions listed above.
02. Using the fixing strap as a template, mark the position for the fixing holes on your mounting surface.
03. Prepare your mounting surface as appropriate for your chosen fixings (not supplied). Use a spirit level to ensure the fitting will be level.
04. Secure the fitting in place.
05. Loosen the bolts at each end of the fixing strap and adjust the angle of your floodlight to give the desired spread of light.
06. Tighten the bolts to lock your floodlight in position.
07. Make the connections to your mains supply as described in the "Read this first" section.
08. Using a cross-headed screwdriver, undo the screws that secure the diffuser and allow to hang down.
09. Fit the fluorescent lamp.
10. Replace the diffuser and tighten the screws making sure that the waterproof gasket is correctly positioned and compressed.
11. Press the trim back onto the front of the fitting making sure the slots used for removal are at the bottom.
12. Restore the power and switch on.

LAMP REPLACEMENT:

01. Switch off the electricity at the mains.
02. Using a cross-headed screwdriver, undo the screws that secure the diffuser and allow to hang down.
03. Remove the lamp.
04. Insert new lamp.
05. Replace the diffuser and secure in position making sure that the gasket is correctly positioned and compressed.
06. Restore the power and switch on.

REPLACEMENT LAMP TYPE:

Fitting requires 1 x 23W ES helical CFLi 6400K (included) or energy saving alternative.

Fitting is rated at 23W max.